





Note: Refer to the MA/MAC6700 Owner's Manual pages 12 and 13 for additional Power Amplifier - Secondary Room connection information. Connection Legend: Data Cable*-Digital Signal Cable -RS232 Cable -Sensor/Keypad Cable -Ground Wire -Power Control Cable* -Audio Signal Cable -AC Power Cords -Video Signal Cable -Loudspeaker Cable -Right Loudspeaker - Secondary Room Left Loudspeaker - Secondary Room RF Signal Cable -* 2 conductor shielded with 1/8 inch stereo mini phone plug on each end. AVIS appropriate and appropria Connect to POWER CONTROL IN OUT O O AC Outlet _ 6 ++ Right Loudspeaker Left Loudspeaker ₹ R OUTPUT LOUTPUT 4 8Ω ⊕ **©** 8Ω ⊕ X C€ ⟨₽⟩ SERIAL NUMBER DIGITAL AUDIO INPUTS ② 2Ω ⊕ SUM 0 \bigcirc \odot (i) DIG 2 0 0 CLASS 2 WIRING \odot 0 0 RS232-C T 6.3AL 250V 0V∕∿50/60 4.4A MtIntosh MA6700 / MAC6700 $\bigcirc\bigcirc$ Connect to $\left(\circ \right)$ $((\circ,\circ)$ AC Outlet